






# PHD-208 Firmware Upgrade Instructions

Firmware Ver. 208.56.21.04:


- (1) Make sure USB Flash Stick is formatted with FAT32.
- (2) Unzip firmware file, (PHD-208\_Firmware-xxx.xx.xx.xx.zip), and copy all files to the root directory of USB Flash stick.
- (3) Turn the unit completely off (unplug AC power cord and see no LED lights on the front panel).
- (4) Firmware upgrade process can be monitored from TV screen. In order to do that, please make sure to connect HDMI cable from TV to PHD-208 HDMI output.
- (5) Insert USB stick to PHD-208 USB port as shown on the picture.
- (6) Turn the unit on by re-plugging AC power cord first. Then Red light is on as the standby mode. After that, push  button on the front panel or POWER key on the remote control to turn on.
- (7) You should see the firmware upgrade screen on your TV right away as shown.
- (8) Wait until you see "Please remove USB flash and reboot." screen showed up.
  - a. Then, remove USB Flash stick and press  button on front panel or POWER key on remote to turn the unit to standby, then press again to turn unit on.
  - b. Or, just wait until the unit self-reboot. Then, remove USB Flash stick. The initial set up menu will be displayed on the screen.



Reading from usb drive and then flashing...



Please remove USB flash and reboot.



Initial screen after Firmware upgrade.  
(Auto-set to 720p output default resolution)