




# PHD-VRX2 Firmware Upgrade Instructions

Firmware Ver. VRX2.244.22.30:  
TV Micro Ver. 3.20

- Channel Logo Selection.

- (1) Make sure USB Flash Stick is formatted with FAT32.
- (2) Unzip firmware file, (PHD\_VRX2\_firmware-VRX2\_xxx\_xx\_xx.zip), and copy all files to root directory of USB Flash stick.
- (3) Make sure the unit is completely off (unplug power AC cord and see no LED lights on the front panel).
- (4) Insert USB stick to any PHD-VRX2 USB port as shown on the picture.
- (5) Turn on the unit by re-plugging AC cord and wait to see 12:00 showing on front panel display. Then, push  power button on the middle of the front panel.
- (6) Very soon, you should see "UPDATE" displayed on the front panel LED readout to indicate firmware upgrade is in progress.
- (7) Wait for a while until you see "no ch" shown on the front panel LED readout and TV should display the initial set up screen.
- (8) In this point, please remove the USB stick and then recycle the power by **completely removing power AC cord**, then turn power on and repeat (3) and (5) two steps.
- (9) Wait again until you see the initial setup menu shown on TV screen. Then follow step by step procedures to complete unit setup with this new firmware.

